

三 极 管 系 列

| 品 名 | 极性 | 管脚 | 功 能 | 参 数 |
|----------|-----|-----|--------|---------------------------------|
| MPSA42 | NPN | 21E | 电话视频放大 | 300V0.5A0.625W |
| MPSA92 | PNP | 21E | 电话视频放大 | 300V0.5A0.625W |
| MPS2222A | NPN | 21 | 高频放大 | 75V0.6A0.625W300MHZ |
| 9011 | NPN | EBC | 高频放大 | 50V30mA0.4W150MHz |
| 9012 | PNP | 贴片 | 低频放大 | 50V0.5A0.625W |
| 9013 | NPN | EBC | 低频放大 | 50V0.5A0.625W |
| 9013 | NPN | 贴片 | 低频放大 | 50V0.5A0.625W |
| 9014 | NPN | EBC | 低噪放大 | 50V0.1A0.4W150MHZ |
| 9015 | PNP | EBC | 低噪放大 | 50V0.1A0.4W150MHZ |
| 9018 | NPN | EBC | 高频放大 | 30V50MA0.4W1GHZ |
| 8050 | NPN | EBC | 高频放大 | 40V1.5A1W100MHZ |
| 8550 | PNP | EBC | 高频放大 | 40V1.5A1W100MHZ |
| 2N2222 | NPN | 4A | 高频放大 | 60V0.8A0.5W25/200NS β =45 |
| 2N2222A | NPN | 小铁 | 高频放大 | 75V0.6A0.625W300MHZ |
| 2N2369 | NPN | 4A | 开关 | 40V0.5A0.3W800MHZ |
| 2N2907 | NPN | 4A | 通用 | 60V0.6A0.4W26/70NS β =200 |
| 2N3055 | NPN | 12 | 功率放大 | 100V15A115W |
| 2N3440 | NPN | 6 | 视放 开关 | 450V1A1W15MHZ |
| 2N3773 | NPN | 12 | 音频功放开关 | 160V16A150W COP 2N6609 |
| 2N3904 | NPN | 21E | 通用 | 60V0.2A β =100-400 |
| 2N3906 | PNP | 21E | 通用 | 40V0.2A β =100-400 |
| 2N5401 | PNP | 21E | 视频放大 | 160V0.6A0.625W100MHZ |
| 2N5551 | NPN | 21E | 视频放大 | 160V0.6A0.625W100MHZ |
| 2N5685 | NPN | 12 | 音频功放开关 | 60V50A300W |
| 2N6277 | NPN | 12 | 功放 开关 | 180V50A250W |
| 2N6609 | PNP | 12 | 音频功放开关 | 160V15A150W COP 2N3773 |

| | | | | |
|---------|-----|-----|---------|--------------------------|
| 2N6678 | NPN | 12 | 音频功放开关 | 650V15A175W15MHZ |
| 2N6718 | NPN | 小铁 | 音频功放开关 | 100V2A2W50MHZ |
| 3DA87A | NPN | 6 | 视频放大 | 100V0.1A1W |
| 3DG6A | NPN | 6 | 通用 | 15V20mA0.1W100MHz |
| 3DG6B | NPN | 6 | 通用 | 20V20mA0.1W150MHz |
| 3DG6C | NPN | 6 | 通用 | 20V20mA0.1W250MHz |
| 3DG6D | NPN | 6 | 通用 | 30V20mA0.1W150MHz |
| 3DG12C | NPN | 7 | 通用 | 45V0.3A0.7W200MHz |
| 3DK2B | NPN | 7 | 开关 | 30V30mA0.2W |
| 3DK4B | NPN | 7 | 开关 | 40V0.8A0.7W |
| 3DK7C | NPN | 7 | 开关 | 25V50mA0.3W |
| 3DD15D | NPN | 12 | 电源开关 | 300V5A50W |
| 3DD102C | NPN | 12 | 电源开关 | 300V5A50W |
| 3522V | | | 5.2V稳压管 | 录像机用 |
| A634 | PNP | 28E | 音频功放开关 | 40V2A10W |
| A708 | PNP | 6 | NF/S | 80V0.7A0.8W |
| A715C | PNP | 29 | 音频功放开关 | 35V2.5A10W160MHZ |
| A733 | PNP | 21 | 通用 | 50V0.1A180MHZ |
| A741 | PNP | 4 | S | 20V0.1A <70/120nS |
| A781 | PNP | 39B | 开关 | 20V0.2A <80/160NS |
| A928 | PNP | ECB | 通用 | 20V1A0.25W |
| A933 | PNP | 21 | Uni | 50V0.1A140MHz |
| A940 | PNP | 28 | 音频功放开关 | 150V1.5A25W4MHZ /C2073 |
| A950 | PNP | 21 | 通用 | 30V0.8A0.6W |
| A966 | PNP | 21 | 音频激励输出 | 30V1.5A0.9W COP:C2236 |
| A968 | PNP | 28 | 音频功放开关 | 160V1.5A25W100MHZ /C2238 |
| A1009 | PNP | BCE | 功放开关 | 350V2A15W |
| A1012 | PNP | 28 | 音频功率放 | 60V5A25W |
| A1013 | PNP | 21 | 视频放大 | 160V1A0.9W |
| A1015 | PNP | 21 | 通用 | 60V0.15A0.4W8MHZ |

| | | | | |
|---------|-----|-----|--------|--------------------------|
| A1020 | PNP | 21 | 音频 开关 | 50V2A0.9W |
| A1123 | PNP | 21 | 低噪放大 | 150V0.05A0.75W |
| A1162 | PNP | 21d | 通用 贴片 | 50V0.15A0.15W |
| A1216 | PNP | BCE | 功放 开关 | 180V17A200W20MHZ /2922 |
| A1220 | PNP | 29 | 音频功放开关 | 120V1.5A20W150MHZ/C2690 |
| A1265 | PNP | BCE | 功放 开关 | 140V10A100W30MHZ /C3182 |
| A1295 | PNP | BCE | 功放 开关 | 230V17A200W30MHZ /C3264 |
| A1301 | PNP | BCE | 功放 开关 | 160V10A100W30MHZ /C3280 |
| A1302 | PNP | BCE | 功放 开关 | 200V15A150W30MHZ /C3281 |
| A1358 ? | PNP | | 高频 | 120V1A10W120MHZ |
| A1444 | PNP | BCE | 高速电源开关 | 100V15A30W80MHZ |
| A1494 | PNP | BCE | 功放 开关 | 200V17A200W20MHZ /C3858 |
| A1516 | PNP | BCE | 功放 开关 | 180V12A130W25MHZ |
| A1668 | PNP | 28B | 电源 开关 | 200V2A25W20MHZ |
| A1785 | PNP | BCE | 驱动 | 400V1A1W/120V1A0.9W140MH |
| A1941 | PNP | BCE | 功放开关 | 140V10A100WCOP:5198 |
| A1943 | PNP | BCE | 功放 开关 | 230V15A150W /C5200 原 |
| A1988 | PNP | 30 | 功放 开关 | |
| B449 | PNP | 12 | 功放开关 | 50V3.5A22.5W 锗管 |
| B631K | PNP | 29 | 音频功放开关 | 120V1A8W130MHZ /D600K |
| B647 | PNP | 21 | 通用 | 120V1A0.9W140MHZ /D667 |
| B649 | PNP | 29 | 视放 | 180V1.5A1W /D669 |
| B669 | PNP | 28 | 达林顿 功放 | 70V4A40W |
| B673 | PNP | 28 | 达林顿 功放 | 100V7A40W |
| B675 | PNP | 28 | 达林顿 功放 | 60V7A40W |
| B688 | PNP | BCE | 音频功放开关 | 120V8A80W /D718 |
| B734 | PNP | 39B | 通用 | 60V1A1W /D774 |
| B744 | PNP | 21 | 通用 | 30V0.1A0.25W |
| B772 | PNP | 29 | 音频功放开关 | 40V3A10W |
| B774 | PNP | 21 | 通用 | 30V0.1A0.25W |

| | | | | |
|-------|-----|-----|--------|---------------------------------|
| B817 | PNP | 30 | 功放开关 | 160V12A100W /D1047 |
| B834 | PNP | 28 | 功放开关 | 60V3A30W |
| B937A | PNP | | 功放开关 | 60V2A35 DRAL |
| B1020 | PNP | 28 | 功放开关 | 达林顿100V7A40W β =6000 |
| B1079 | PNP | 30 | 达林顿功放 | 100V20A100W β =5000/D1559 |
| B1185 | PNP | 28B | 功放开关 | 60V3A25W 70MHZ /D1762 |
| B1238 | PNP | ECB | 功放开关 | 80V0.7A1W 100MHZ |
| B1240 | PNP | 39B | 功放开关 | 40V2A1W100HZ |
| B1243 | PNP | 39B | 功放开关 | 40V3A1W70HZ |
| B1316 | PNP | 54B | 驱动功放 | 达林顿100V2A10W β =15000 |
| B1317 | PNP | BCE | 音频功放 | 180V15A150W COP:D1975 |
| B1335 | PNP | 28 | 音频功放低噪 | 80V4A30W 12MHZ |
| B1375 | PNP | BCE | 音频功放 | 60V3A2W9MHZ |
| B1400 | PNP | 28B | 达林顿功放 | 120V6A25W β =1000-20000 |
| B1429 | PNP | BCE | 功放开关 | 180V15A150W |
| B1494 | PNP | BCE | 达林顿功放 | 120V25A120W β =2000-20000 |
| C106 | NPN | EBC | 音频功放开关 | 60V1.5A15W |
| C380 | NPN | 21 | 高频放大 | 35V0.03A250MHZ |
| C458 | NPN | 21 | 通用 | 30V0.1A230MHz |
| C536 | NPN | 21 | 通用 | 40V0.1A180MHZ |
| C752 | NPN | 21 | 通用 | 30V0.1A300MHZ |
| C815 | NPN | 21 | 通用 | 60V0.2A0.25W |
| C828 | NPN | 21 | 通用 | 45V0.05A0.25W |
| C900 | NPN | 21 | 低噪放大 | 30V0.03A100MHZ |
| C943 | NPN | 4A | 通用 | 60V0.2A200MHZ |
| C945 | NPN | 21 | 通用 | 50V0.1A0.5W250MHZ |
| C1008 | NPN | 6 | 通用 | 80V0.7A0.8W50MHZ |
| C1162 | NPN | 29 | 音频功放开关 | 35V1.5A10W |
| C1213 | NPN | 39B | 监视器专用 | 35V0.5A0.4W |
| C1222 | NPN | 21 | 低噪放大 | 60V0.1A100MHZ |

| | | | | |
|---------|-----|-----|--------|-------------------------|
| C1494 ? | NPN | 40A | 发射 | 36V6A PQ=40W/175MHZ |
| C1507 | NPN | 28 | 视放 | 300V0.2A15W |
| C1674 | NPN | 21 | HF/ZF | 30V0.02A600MHZ |
| C1815 | NPN | 21 | 通用 | 60V0.15A0.4W8MHZ |
| C1855 | NPN | 21f | HF/ZF | 20V0.02A550MHZ |
| C1875 | NPN | 12 | 彩行 | 1500V3.5A50W |
| C1906 | NPN | 21 | 高频放大 | 30V0.05A1000MHZ |
| C1942 | NPN | 12 | 彩行 | 1500V3A50W |
| C1959 | NPN | 21 | 通用 | 30V0.4A0.5W300MHZ |
| C1970 | NPN | 28 | 手机发射 | 40V0.6A PQ=1.3W/175MHZ |
| C1971 | NPN | 28A | 手机发射 | 35V2.0A PQ=7.0W/175MHZ |
| C1972 | NPN | 28A | 手机发射 | 35V3.5A PQ=15W/175MHZ |
| C2012 | NPN | 21 | HF | 30V0.03A200MHZ |
| C2027 | NPN | 12 | 行管 | 1500V5A50W |
| C2036 | | | | |
| C2068 | NPN | 28E | 视频放大 | 300V0.05A1.5W80MHZ |
| C2073 | NPN | 28 | 功率放大 | 150V1.5A25W4MHZ /A940 |
| C2078 | NPN | 28 | 音频功放开关 | 80V3A10W150MHZ |
| C2120 | NPN | 21 | 通用 | 30V0.8A0.6W |
| C2228 | NPN | 21 | 视频放大 | 160V0.05A0.75W |
| C2230 | NPN | 21 | 视频放大 | 200V0.1A0.8W |
| C2233 | NPN | 28 | 音频功放开关 | 200V4A40W |
| C2236 | NPN | 21 | 通用 | 30V1.5A0.9W /A966 |
| C2238 | NPN | 28 | 音频功放开关 | 160V1.5A25W100MHZ /A968 |
| C2320 | NPN | 21 | 通用 | 50V0.2A0.3W200MHZ |
| C2335 | NPN | 28 | 视频 功放 | 500V7A40W |
| C2373 | NPN | 28 | 功放 | 200V7.5A40W |
| C2383 | NPN | 21 | 视频 开关 | 160V1A0.9W /A1015 |
| C2443 | NPN | 大铁 | 功放开关 | 600V50A400W |
| C2481 | NPN | 29 | 音频功放开关 | 150V1.5A20W |

| | | | | |
|-------|-----|-----|--------|-------------------------------|
| C2482 | NPN | 21 | 视频放大 | 300V0.1A0.9W |
| C2500 | NPN | 21 | 通用 | 30V2A0.9W150MHZ |
| C2594 | NPN | 29 | 音频功放开关 | 40V5A10W |
| C2611 | NPN | 29 | 视频放大 | 300V0.1A1.25W |
| C2625 | NPN | 30 | 音频功放开关 | 450V10A80W |
| C2682 | NPN | 29 | NF/Vid | 180V0.1A8W |
| C2688 | NPN | 29 | 视放管 | 300V0.2A10W80MHZ |
| C2690 | NPN | 29 | 音频功放开关 | 120V1.2A20W150MHZ/A1220P |
| C2751 | NPN | BCE | 电源开关 | 500V15A120W $\beta=40$ |
| C2837 | NPN | 30 | 音频功放开关 | 150V10A100W |
| C2898 | NPN | 28 | 音频功放开关 | 500V8A50W |
| C2922 | NPN | 43 | 音频功放开关 | 180V17A200W50MHZ /A1216 |
| C3026 | NPN | 12 | 开关管 | 1700V5A50W $\beta=20$ |
| C3030 | NPN | BCE | 开关管 | 达林顿900V7A80W $\beta=15$ |
| C3039 | NPN | 28 | 电源开关 | 500V7A50W $\beta=40$ |
| C3058 | NPN | 12 | 开关管 | 600V30A200W $\beta=15$ |
| C3148 | NPN | 28 | 电源开关 | 900V3A40W $\beta=15$ |
| C3150 | NPN | 28 | 电源开关 | 900V3A50W $\beta=15$ |
| C3153 | NPN | 30 | 电源开关 | 900V6A100W $\beta=15$ |
| C3182 | NPN | 30 | 功放开关 | 140V10A100W $\beta=95/A1265$ |
| C3198 | NPN | 21 | 高频放大 | 60V0.15A0.4W130MHZ |
| C3262 | NPN | BCE | 达林顿功放 | 800V10A100W |
| C3264 | NPN | BCE | PA功放开关 | 230V17A200W $\beta=170/A1295$ |
| C3280 | NPN | 30 | 音频功放开关 | 160V12A120W $\beta=100$ |
| C3281 | NPN | 30 | 音频功放开关 | 200V15A150W30MHZ $\beta=100$ |
| C3300 | NPN | 30 | 音频功放开关 | 100V15A100W $\beta=600$ |
| C3310 | NPN | 28C | 电源开关 | 500V5A40W $\beta= 20$ |
| C3320 | NPN | 28C | 电源开关 | 500V15A80W $\beta= 15$ |
| C3355 | NPN | 21F | 高频放大 | 20V0.1A6500MHZ |
| | | | | |

| | | | | |
|-------|-----|-----|--------|-------------------------|
| C3358 | NPN | 40B | 高频放大 | 20V0.1A7000MHZ |
| C3457 | NPN | BCE | 电源开关 | 1100V3A50W $\beta=12$ |
| C3460 | NPN | BCE | 电源开关 | 1100V6A100W $\beta=12$ |
| C3466 | NPN | BCE | 电源开关 | 1200V8A120W $\beta=10$ |
| C3505 | NPN | 28B | 电源开关 | 900V6A80W $\beta=20$ |
| C3527 | NPN | BCE | 电源开关 | 500V15A100W $\beta=13$ |
| C3528 | NPN | BCE | 电源开关 | 500V20A150W $\beta=13$ |
| C3595 | NPN | 29 | 射频 | 30V0.5A1.2W $\beta=90$ |
| C3679 | NPN | BCE | 电源开关 | 900V5A100W6MHZ |
| C3680 | NPN | BCE | 电源开关 | 900V7A120W6MHZ |
| C3688 | NPN | BCE | 彩行 | 1500V10A150W |
| C3720 | NPN | BCE | 彩行 | 1200V10A200W |
| C3783 | NPN | BCE | 高压高速开关 | 900V5A100W 黄河21" |
| C3795 | NPN | BCE | 高压高速开关 | 900V5A2W8MHz |
| C3807 | NPN | BCE | 低噪放大 | 30V2A1.2W260MHZ |
| C3858 | NPN | BCE | 功放开关 | 200V17A200W20MHZ /A1494 |
| C3866 | NPN | BCE | 高压高速开关 | 900V3A40W |
| C3873 | NPN | BCE | 高压高速开关 | 500V12A75W30MHZ |
| C3886 | NPN | BCE | 开关,行管 | 1400V8A50W8MHZ |
| C3893 | NPN | 28B | 行管 | 1400V8A50W8MHZ |
| C3907 | NPN | 28B | 功放开关 | 180V12A130W30MHZ |
| C3953 | NPN | 29 | 视放 | 120V0.2A1.3W 4000MHZ |
| C3987 | NPN | 28 | 达林顿 | 50V3A20W $\beta=1000$ |
| C3995 | NPN | BCE | 行管 | 1500V12A180W 34寸 |
| C3997 | NPN | BCE | 行管 | 1500V15A250W |
| C3998 | NPN | BCE | 行管 | 1500V25A250W |
| C4024 | NPN | BCE | 功放开关 | 100V10A35W 24MHZ |
| C4038 | NPN | BCE | 门电路 | 50V0.1A0.3W180MHZ |
| C4059 | NPN | BCE | 高速开关 | 600V15A130W 0.5/2.2US |
| C4106 | NPN | BCE | 电源开关 | 500V7A50W20MHZ? |

| | | | | |
|--------|-----|-----|-----------|----------------------|
| C4111 | NPN | BCE | 开关 行管 | 1500V10A150W |
| C4119 | NPN | BCE | 微波炉 开关 | 1500V15A250W |
| C4231 | NPN | 50C | 音频功放 | 800V2A30W |
| C4237 | NPN | BCE | 高压高速开关 | 1000V8A120W30MHZ |
| C4242 | NPN | BCE | 高压高速开关 | 450V7A40W |
| C4288 | NPN | BCE | 行管 | 1400V12A200W8MHZ |
| C4297 | NPN | BCE | 电源开关 | 500V12A75W10MHZ |
| C4429 | NPN | BCE | 电源开关 | 1100V8A60W |
| C4517 | NPN | BCE | 音频功放 | 550V3A30W6MHZ |
| C4532 | NPN | BCE | | |
| C4582 | NPN | 28b | 电源开关 | 600V15A75W20MHZ |
| ON4673 | NPN | BCE | | |
| ON4873 | NPN | BCE | | |
| C4706 | NPN | BCE | 电源开关 | 900V14A130W6MHz |
| C4742 | NPN | 46 | 彩行 | 1500V6A50W(带阻尼) |
| C4745 | NPN | 46 | 彩行 | 1500V6A50W |
| C4747 | NPN | 46 | 彩行 | 1500V10A50W |
| C4769 | NPN | BCE | 微机行管 | 1500V7A60W(带阻尼) |
| C4913 | NPN | BCE | 大屏视放管 | 2000V0.2A35W |
| C4924 | NPN | BCE | 音频功放 | 800V10A70W |
| C4927 | NPN | BCE | 行管 | 1500V8A50W |
| C4927 | NPN | BCE | SONY29"行管 | 1500V8A50W 原装 |
| C4941 | NPN | BCE | 行管 | 1500V6A65W 500/380NS |
| C4953 | NPN | BCE | | 500V2A25W |
| C5020 | NPN | BCE | 彩行 | 1000V7A100W |
| C5068 | NPN | BCE | 彩行 | 1500V10A50W |
| C5086 | NPN | BCE | 彩行 | 1500V10A50W |
| C5088 | NPN | BCE | 彩行 | 1500V10A50W |
| C5129 | NPN | BCE | 彩显行管 | 1500V8A50W(带阻) |
| C5132 | NPN | BCE | 彩行 | 1500V16A50W |

| | | | | |
|-------|-----|-----|--------|-----------------------|
| C5144 | NPN | BCE | 大屏彩行 | 1700V20A200W |
| C5148 | NPN | BCE | | |
| C5149 | NPN | BCE | 高速高频行管 | 1500V8A50W(带阻) |
| C5198 | NPN | BCE | 功放开关 | 140V10A100W |
| C5200 | NPN | BCE | 功放开关 | 230V15A150W /A1943 原 |
| C5207 | NPN | BCE | 彩行 | 1500V10A50W 原 |
| C5243 | NPN | BCE | 彩行 | 1700V15A200W 原 |
| C5244 | NPN | BCE | 彩行 | 1700V15A200W |
| C5249 | NPN | BCE | | |
| C5250 | NPN | BCE | 开关 | 1000V7A100W 原 |
| C5251 | NPN | BCE | 彩行 | 1500V12A50W 原 |
| C5252 | NPN | BCE | 彩行 | 1500V15A100W 原 |
| C5294 | NPN | BCE | | |
| C5296 | NPN | BCE | 开关管 | 25"--34"大屏彩显电源管 |
| C5297 | NPN | BCE | 开关管 | 25"--34"大屏彩显电源管 |
| C5331 | NPN | BCE | 大屏彩显行管 | 1500V15A180W |
| C5423 | NPN | BCE | | |
| D40C | NPN | ECB | 对讲机用 | 40V0.5A40W75MHZ(达林顿) |
| D325 | NPN | BCE | 功放开关 | 50V3A25W |
| D385 | NPN | 11 | 达林顿功放 | 100V7A30W |
| D400 | NPN | 21 | 通用 | 25V1A0.75W |
| D401 | NPN | 28 | 音频功放开关 | 200V2A20W |
| D415 | NPN | 29 | 音频功放开关 | 120V0.8A5W |
| D438 | NPN | 21 | 通用 | 500V1A0.75W100MHz |
| D547 | NPN | 大铁 | 功放开关 | 600V50A400W |
| D560 | NPN | BCE | 达林顿功放 | 150V5A30W |
| D600K | NPN | 29 | 音频功放开关 | 120V1A8W130MHZ/B631K |
| D637 | NPN | 39E | 通用 | 60V0.1A150MHZ **** |
| D667 | NPN | 21 | 视频放大 | 120V1A0.9W140MHZ/B647 |
| D669 | NPN | 29 | 视频放大 | 180V1.5A1W140MHZ/D669 |

| | | | | |
|--------|-----|-----|--------|-------------------------------|
| D718 | NPN | 30 | 音频功放开关 | 120V8A80W /B668 |
| D774 | NPN | 39B | 通用 | 100V1A1W /B734 |
| D789 | NPN | 21 | 音频输出 | 100V1A0.9W |
| D820 | NPN | 12 | 彩行 | 1500V5A50W |
| D870 | NPN | 12 | 彩行 | 1500V5A50W RRRR |
| D880 | NPN | 28 | 音频功放开关 | 60V3A10W |
| D882 | NPN | 29 | 音频功放开关 | 40V3A30W |
| D884 | NPN | 28 | 音频功放开关 | 330V7A40W |
| D898 | NPN | 12 | 彩行 | 1500V3A50W |
| D951 | NPN | 12 | 彩行 | 1500V3A65W |
| D965 | NPN | 21 | 音频 | 40V5A0.75W |
| D966 | NPN | 21 | 音频 | 40V5A1W |
| D985 | NPN | 29 | 功放 | 150V1.5A10W |
| D986 | NPN | 29 | 功放 | 150V1.5A10W |
| D1025 | NPN | 28 | 达林顿功放 | 200V8A50W |
| D1037 | NPN | BCE | 音频功放开关 | 150V30A180W |
| D1047 | NPN | 30 | 音频功放开关 | 160V12A100W /B817 |
| D1071 | NPN | 28 | 功放 | 300V6A40W DRA-L |
| D1163A | NPN | 28 | 行偏转用 | 350V7A40W60MHz |
| D1175 | NPN | 12 | 行偏转用 | 1500V5A100W $\beta=15$ 原 |
| D1273 | NPN | 28 | 音频功放 | 80V3A40W50MHZ $\beta=1500$ |
| D1302 | NPN | 21 | 音频 | 25V0.5A0.5W200MHZ |
| D1397 | NPN | BCE | 开关 | 1500V3.5A50W3MHz |
| D1398 | NPN | BCE | 开关 | 1500V5A50W3MHz |
| D1403 | NPN | 28B | 彩行 | 1500V6A120W |
| D1403 | NPN | 28B | 彩行 | 1500V6A120W 原 |
| D1415 | NPN | 28B | 功放电源开关 | 100V7A40W $\beta=6000$ 达林顿 |
| D1416 | NPN | 28B | 功放电源开关 | 80V7A40W $\beta=6000$ (达林顿) |
| D1426 | NPN | 28B | 彩行 | 1500V3.5A80W $\beta=12$ RRRRR |
| D1427 | NPN | 28B | 彩行 | 1500V5A80W $\beta=12$ RRRRR |

| | | | | |
|-------|-----|-----|--------|---------------------------------|
| D1428 | NPN | 28B | 彩行 | 1500V6A80W $\beta=12$ RRRR |
| D1431 | NPN | 28B | 彩行 | 1500V5A80W $\beta=20$ |
| D1433 | NPN | 28B | 彩行 | 1500V7A80W $\beta=20$ |
| D1439 | NPN | BCE | 彩行 | 1500V3A80W $\beta=8$ |
| D1541 | NPN | 28B | 彩行 | 1500V3A80W $\beta=20$ |
| D1545 | NPN | 28B | 彩行 | 1500V5A50W $\beta=20$ |
| D1547 | NPN | BCE | 彩行 | 1500V7A80W $\beta=20$ |
| D1554 | NPN | BCE | 彩行 | 1500V3.5A80W $\beta=12$ |
| D1555 | NPN | BCE | 彩行 | 1500V5A80W $\beta=12$ |
| D1556 | NPN | BCE | 彩行 | 1500V6A80W $\beta=12$ |
| D1559 | NPN | BCE | 达林顿功放 | 100V20A100W $\beta=5000$ /B1079 |
| D1590 | NPN | 28 | 达林顿功放 | 150V8A25W $\beta=15000$ |
| D1632 | NPN | 28B | 彩行 | 1500V4A70W |
| D1640 | NPN | 29 | 达林顿功放 | 120V2A1.2W $\beta=4000-40000$ |
| D1651 | NPN | SP | 彩行 | 1500V5A60W3MHZ |
| D1710 | NPN | BCE | 彩行 | 1500V5A50W |
| D1718 | NPN | 28C | 音频功放 | 180V15A3.5W20MHZ |
| D1762 | NPN | BCE | 音频功放开关 | 60V3A25W90MHZ /B1185 |
| D1843 | NPN | BCE | 低噪 放大 | 50V1A1W |
| D1849 | NPN | 50A | 彩行 | 1500V7A120W |
| D1850 | NPN | 50A | 彩行 | 1500V7A120W |
| D1859 | NPN | 50A | 音频 | 80V0.7A1W120MHZ |
| D1863 | NPN | 50A | 音频 | 120V1A1W100MHZ |
| D1877 | NPN | 30 | 彩行 | 1500V4A50W(带阻尼) |
| D1879 | NPN | 30 | 彩行 | 1500V6A60W(带阻尼) |
| D1887 | NPN | 30 | 彩行 | 1500V10A70W |
| D1930 | NPN | 21 | 达林顿 | 达林顿100V2A1.2W $\beta=1000$ |
| D1975 | NPN | 53A | 音频功放 | 180V15A150W COP:B1317 |
| D1978 | NPN | 21 | 达林顿 | 120V1.5A0.9W $\beta=30000$ |
| | | | | |

| | | | | |
|--------|-----|-----|--------|---------------------------------|
| D1980 | NPN | 61B | 达林顿 | 100V2A10W β =1000-10000 |
| D1981 | NPN | ECB | 达林顿 | 100V2A1W |
| D1993 | NPN | 45B | 音频低噪 | 55V0.1A0.4W |
| D1994A | NPN | ECB | 音频驱动 | 60V1A1W |
| D1997 | NPN | 45B | 激励管 | 40V3A1.5W100MHZ |
| D2008 | NPN | ECB | 音频功放 | 80V1A1.2W |
| D2012 | NPN | BCE | 音频功放 | 60V3A2W3MHZ |
| D2136 | NPN | ECB | 功放 | 80V1A1.2W |
| D2155 | NPN | 53A | 音频功放 | 180V15A150W |
| D2256 | NPN | 46 | 达林顿功放 | 120V25A125W β =2000-20000 |
| D2334 | NPN | 28B | 彩行 | 1500V5A80W |
| D2335 | NPN | BCE | 彩行 | 1500V7A100W |
| D2349 | NPN | BCE | 大屏彩显行管 | |
| D2374 | NPN | BCE | | |
| D2375 | NPN | BCE | | |
| D2388 | NPN | EBC | 达林顿 | 90V3A1.2W |
| D2445 | NPN | BCE | 彩行 | 1500V12.5A120W |
| D2498 | NPN | BCE | 彩行 | 1500V6A50W |
| D2588 | NPN | BCE | 点火器用 | |
| DK55 | NPN | BEC | 开关 | 400V4A60W |
| BC307 | PNP | 21a | 通用 | 50V0.2A0.3W |
| BC327 | PNP | CBE | 低噪 音频 | 50V0.8A0.625W COM BC337 |
| BC337 | NPN | 21a | 音频激励低噪 | 50V0.8A0.625W COM BC327 |
| BC338 | NPN | 21a | 通用 激励 | 50V0.8A0.6 |
| BC546 | NPN | 21a | 通用 | 80V0.2A0.5W |
| BC547 | NPN | CBE | 通用 | 50V0.2A0.5W300MHZ |
| BD135 | NPN | 29 | 音频 功放 | 45V1.5A12.5W |
| BD136 | PNP | 29 | 音频 功放 | 45V1.5A12.5W |
| BD137 | NPN | 29 | 音频 功放 | 60V1.5A12.5W |
| BD138 | PNP | 29 | 音频 功放 | 60V1.5A12.5W |

| | | | | |
|----------|-----|----|-------|------------------------|
| BD139 | PNP | 29 | 音频 功放 | 80V1.5A12.5W |
| BD237 | NPN | 29 | 音频 功放 | 100V2A25W |
| BD238 | PNP | 29 | 音频 功放 | 100V2A25W |
| BD243 | NPN | 28 | 音频 功放 | 45V6A65W |
| BD244 | PNP | 28 | 音频 功放 | 45V6A65W |
| BD681 | NPN | 29 | 达林顿功放 | 100V4A40W |
| BD682 | NPN | 29 | 达林顿功放 | 100V4A40W |
| BF458 | NPN | 29 | 视放 | 250V0.1A10W |
| BU208A | NPN | 12 | 彩行 | 1500V5A12.5W |
| BU208D | NPN | 12 | 彩行 | 1500V5A12.5W (带阻尼) |
| BU323 | NPN | 28 | 达林顿功放 | 450V10A125W |
| BU406 | NPN | 28 | 行管 | 400V7A60W |
| BU508A | NPN | 28 | 行管 | 1500V7.5A75W |
| BU508A | NPN | 28 | 行管 | 1500V7.5A75W 原 |
| BU508D | NPN | 28 | 行管 | 1500V7.5A75W (带阻尼) |
| BU806 | NPN | 28 | 功放 | 400V8A60W DAR-L |
| BU932R | NPN | 12 | 功放 | 500V15A150W DAR-L |
| BU941 | NPN | 12 | | |
| BU1508DX | NPN | 28 | 开关 功放 | |
| BU2506DX | NPN | 30 | 开关 功放 | 1500V7A50W /600NS |
| BU2508AF | NPN | 30 | 开关 功放 | 700V8A125W /600NS |
| BU2508AX | NPN | 30 | 开关 功放 | 700V8A125W /600NS |
| BU2508DF | NPN | 30 | 开关 功放 | 700V8A125W/600NS(带阻尼) |
| BU2508DX | NPN | 30 | 开关 功放 | 1500V8A50W/600NS(带阻尼) |
| BU2520AF | NPN | 30 | 开关 功放 | 800V10A150W 1/500NS |
| BU2520AX | NPN | 30 | 开关 功放 | 1500V10A150W 1/500NS |
| BU2520DF | NPN | 30 | 开关 功放 | 800V10A150W1/500NS(带阻) |
| BU2520DX | NPN | 30 | 开关 功放 | 1500V10A50W/600NS (带阻) |
| BU2522AF | NPN | 30 | 开关 功放 | 1500V11A150W /350NS |
| BU2522AX | NPN | 30 | 开关 功放 | 1500V11A150W /350NS |

| | | | | |
|----------|-----|-----|---------|------------------------|
| BU2525AF | NPN | 30 | 开关 功放 | 1500V12A150W /350NS |
| BU2525AX | NPN | 30 | 开关 功放 | 1500V12A150W /350NS |
| BU2527AF | NPN | 30 | 开关 功放 | 1500V15A150W |
| BU2532AW | NPN | 30 | 开关 功放 | 1500V15A150W(大屏) |
| BUH515 | NPN | BCE | 行管 | 1500V10A80W |
| BUH515D | NPN | BCE | 行管 | 1500V10A80W(带阻尼) |
| BUS13A | NPN | 12 | 开关 功放 | 1000V15A175W |
| BUS14A | NPN | 12 | 开关 功放 | 1000V30A250W |
| BUT11A | NPN | 28 | 开关 功放 | 1000V5A100W |
| BUT12A | NPN | 28 | 开关 功放 | 450V10A125W |
| BUV26 | NPN | 28 | 音频功放开关 | 90V14A65W /250ns |
| BUV28A | NPN | 28 | 音频功放开关 | 225V10A65W /250ns |
| BUV48A | NPN | 30 | 音频功放开关 | 450V15A150W |
| BUW13A | NPN | 30 | 功放开关 | 1000V15A150W |
| BUX48 | NPN | 12 | 功放开关 | 850V15A125W |
| BUX84 | NPN | 30 | 功放开关 | 800V2A40W |
| BUX98A | NPN | 12 | 功放开关 | 400V30A210W5MHZ |
| DTA114 | PNP | | 10K-10K | 160V0.6A0.625W(带阻) |
| DTC143 | NPN | | 录像机用 | 4.7K-4.7K |
| HPA100 | NPN | BCE | 大屏彩显行管 | 21# |
| HPA150 | NPN | BCE | 大屏彩显行管 | 21# |
| HSE830 | PNP | BCE | 音频功放 | 80V115W1MHZ |
| HSE838 | NPN | BCE | 音频功放 | 80V115W1MHZ COP/MJ4502 |
| MN650 | NPN | BCE | 行管 | 1500V6A80W |
| MJ802 | NPN | 12 | 音频功放开关 | 90V30A200W |
| MJ2955 | PNP | 12 | 音频功放开关 | 60V15A115W |
| MJ3055 | NPN | 12 | 音频功放开关 | 60V15A115W |
| MJ4502 | PNP | 12 | 音频功放开关 | 90V30A200W COP/MJ802 |
| MJ10012 | NPN | 12 | 达林顿 | 400V10A175W |
| MJ10015 | NPN | 12 | 电源开关 | 400V50A200W |

| | | | | |
|----------|-----|-----|--------|-------------------------|
| MJ10016 | NPN | 12 | 电源开关 | 500V50A200W |
| MJ10025 | | 12 | 电源开关 | 850V20A250W |
| MJ11032 | NPN | 12 | 电源开关 | 120V50A300W DAR-L |
| MJ11033 | PNP | 12 | 电源开关 | 120V50A300W DAR-L |
| MJ13333 | NPN | 12 | 电源开关 | 400V20A175W |
| MJ15024 | NPN | 12 | 音频功放开关 | 400V16A250W4MHZ(原25.00) |
| MJ15025 | PNP | 12 | 音频功放开关 | 400V16A250W4MHZ(原25.00) |
| MJE271 | PNP | 29 | 达林顿 | |
| MJE340 | NPN | 29 | 视放 | 300V0.5A20W |
| MJE350 | PNP | 29 | 视放 | 300V0.5A20W |
| MJE2955T | PNP | BCE | 音频功放开关 | 60V1075W2MHZ |
| MJE3055T | NPN | BCE | 音频功放开关 | 70V1075W2MHZ |
| MJE5822 | PNP | BCE | 音频功放开关 | 500V8A |
| MJE9730 | NPN | BCE | | |
| MJE13003 | NPN | 29 | 功放开关 | 400V1.5A14W |
| MJE13005 | NPN | 28 | 功放开关 | 400V4A60W |
| MJE13007 | NPN | 28 | 功放开关 | 1500V2.5A60W |
| SE800 | | | | |
| TIP31C | NPN | BCE | 功放开关 | 100V3A40W3MHZ |
| TIP32C | PNP | BCE | 功放开关 | 100V3A40W3MHZ |
| TIP35C | NPN | 30 | 音频功放开关 | 100V25A125W3MHZ |
| TIP36C | PNP | 30 | 音频功放开关 | 100V25A125W3MHZ |
| TIP41C | NPN | 30 | 音频功放开关 | 100V6A65W3MHZ |
| TIP42C | PNP | 30 | 音频功放开关 | 100V6A65W3MHZ |
| TIP102 | NPN | 28 | 音频功放开关 | 100V8A2W |
| TIP105 | | 28 | 音频功放开关 | |
| TIP122 | NPN | 28 | 音频功放开关 | 100V8A65W DARL |
| TIP127 | PNP | 28 | 音频功放开关 | 100V8A65W DARL |
| TIP137 | PNP | 28 | 音频功放开关 | 100V8A70W DARL |
| TIP142 | NPN | 30 | 音频功放开关 | 100V10A125W DAR-L |

| | | | | |
|---------|-----|-----|--------|---------------------|
| TIP142大 | NPN | 30 | 音频功放开关 | 100V10A125W DAR-L |
| TIP147 | PNP | 30 | 音频功放开关 | 100V10A125W DAR-L 0 |
| TIP147大 | PNP | 30 | 音频功放开关 | 100V10A125W DAR-L 0 |
| TIP152 | | | 电梯用 | |
| TL431 | | 21 | 电压基准源 | |
| UGN3120 | | SGO | 霍尔开关 | |
| UGN3144 | | SGO | 霍尔开关 | |
| 60MIAL1 | | | 电磁/微波炉 | 1000V60A300W |
| T30G40 | NPN | BCE | 大功率开关管 | 400V30A300W |
| 5609 | | | | COML:5610 |
| 5610 | | | | COML:5609 |
| 9626 | | | | NPN21 通用 |

三 极 管 系 列

| 品 名 | 极性 | 管脚 | 功 能 | 参 数 |
|----------|-----|-----|--------|---------------------------------|
| MPSA42 | NPN | 21E | 电话视频放大 | 300V0.5A0.625W |
| MPSA92 | PNP | 21E | 电话视频放大 | 300V0.5A0.625W |
| MPS2222A | NPN | 21 | 高频放大 | 75V0.6A0.625W300MHZ |
| 9011 | NPN | EBC | 高频放大 | 50V30mA0.4W150MHz |
| 9012 | PNP | 贴片 | 低频放大 | 50V0.5A0.625W |
| 9013 | NPN | EBC | 低频放大 | 50V0.5A0.625W |
| 9013 | NPN | 贴片 | 低频放大 | 50V0.5A0.625W |
| 9014 | NPN | EBC | 低噪放大 | 50V0.1A0.4W150MHZ |
| 9015 | PNP | EBC | 低噪放大 | 50V0.1A0.4W150MHZ |
| 9018 | NPN | EBC | 高频放大 | 30V50MA0.4W1GHZ |
| 8050 | NPN | EBC | 高频放大 | 40V1.5A1W100MHZ |
| 8550 | PNP | EBC | 高频放大 | 40V1.5A1W100MHZ |
| 2N2222 | NPN | 4A | 高频放大 | 60V0.8A0.5W25/200NS β =45 |
| 2N2222A | NPN | 小铁 | 高频放大 | 75V0.6A0.625W300MHZ |
| 2N2369 | NPN | 4A | 开关 | 40V0.5A0.3W800MHZ |
| 2N2907 | NPN | 4A | 通用 | 60V0.6A0.4W26/70NS β =200 |
| 2N3055 | NPN | 12 | 功率放大 | 100V15A115W |
| 2N3440 | NPN | 6 | 视放 开关 | 450V1A1W15MHZ |
| 2N3773 | NPN | 12 | 音频功放开关 | 160V16A150W COP 2N6609 |
| 2N3904 | NPN | 21E | 通用 | 60V0.2A β =100-400 |
| 2N3906 | PNP | 21E | 通用 | 40V0.2A β =100-400 |
| 2N5401 | PNP | 21E | 视频放大 | 160V0.6A0.625W100MHZ |
| 2N5551 | NPN | 21E | 视频放大 | 160V0.6A0.625W100MHZ |
| 2N5685 | NPN | 12 | 音频功放开关 | 60V50A300W |
| 2N6277 | NPN | 12 | 功放 开关 | 180V50A250W |
| 2N6609 | PNP | 12 | 音频功放开关 | 160V15A150W COP 2N3773 |

| | | | | |
|---------|-----|-----|---------|--------------------------|
| 2N6678 | NPN | 12 | 音频功放开关 | 650V15A175W15MHZ |
| 2N6718 | NPN | 小铁 | 音频功放开关 | 100V2A2W50MHZ |
| 3DA87A | NPN | 6 | 视频放大 | 100V0.1A1W |
| 3DG6A | NPN | 6 | 通用 | 15V20mA0.1W100MHz |
| 3DG6B | NPN | 6 | 通用 | 20V20mA0.1W150MHz |
| 3DG6C | NPN | 6 | 通用 | 20V20mA0.1W250MHz |
| 3DG6D | NPN | 6 | 通用 | 30V20mA0.1W150MHz |
| 3DG12C | NPN | 7 | 通用 | 45V0.3A0.7W200MHz |
| 3DK2B | NPN | 7 | 开关 | 30V30mA0.2W |
| 3DK4B | NPN | 7 | 开关 | 40V0.8A0.7W |
| 3DK7C | NPN | 7 | 开关 | 25V50mA0.3W |
| 3DD15D | NPN | 12 | 电源开关 | 300V5A50W |
| 3DD102C | NPN | 12 | 电源开关 | 300V5A50W |
| 3522V | | | 5.2V稳压管 | 录像机用 |
| A634 | PNP | 28E | 音频功放开关 | 40V2A10W |
| A708 | PNP | 6 | NF/S | 80V0.7A0.8W |
| A715C | PNP | 29 | 音频功放开关 | 35V2.5A10W160MHZ |
| A733 | PNP | 21 | 通用 | 50V0.1A180MHZ |
| A741 | PNP | 4 | S | 20V0.1A <70/120nS |
| A781 | PNP | 39B | 开关 | 20V0.2A <80/160NS |
| A928 | PNP | ECB | 通用 | 20V1A0.25W |
| A933 | PNP | 21 | Uni | 50V0.1A140MHz |
| A940 | PNP | 28 | 音频功放开关 | 150V1.5A25W4MHZ /C2073 |
| A950 | PNP | 21 | 通用 | 30V0.8A0.6W |
| A966 | PNP | 21 | 音频激励输出 | 30V1.5A0.9W COP:C2236 |
| A968 | PNP | 28 | 音频功放开关 | 160V1.5A25W100MHZ /C2238 |
| A1009 | PNP | BCE | 功放开关 | 350V2A15W |
| A1012 | PNP | 28 | 音频功率放 | 60V5A25W |
| A1013 | PNP | 21 | 视频放大 | 160V1A0.9W |
| A1015 | PNP | 21 | 通用 | 60V0.15A0.4W8MHZ |

| | | | | |
|---------|-----|-----|--------|--------------------------|
| A1020 | PNP | 21 | 音频 开关 | 50V2A0.9W |
| A1123 | PNP | 21 | 低噪放大 | 150V0.05A0.75W |
| A1162 | PNP | 21d | 通用 贴片 | 50V0.15A0.15W |
| A1216 | PNP | BCE | 功放 开关 | 180V17A200W20MHZ /2922 |
| A1220 | PNP | 29 | 音频功放开关 | 120V1.5A20W150MHZ/C2690 |
| A1265 | PNP | BCE | 功放 开关 | 140V10A100W30MHZ /C3182 |
| A1295 | PNP | BCE | 功放 开关 | 230V17A200W30MHZ /C3264 |
| A1301 | PNP | BCE | 功放 开关 | 160V10A100W30MHZ /C3280 |
| A1302 | PNP | BCE | 功放 开关 | 200V15A150W30MHZ /C3281 |
| A1358 ? | PNP | | 高频 | 120V1A10W120MHZ |
| A1444 | PNP | BCE | 高速电源开关 | 100V15A30W80MHZ |
| A1494 | PNP | BCE | 功放 开关 | 200V17A200W20MHZ /C3858 |
| A1516 | PNP | BCE | 功放 开关 | 180V12A130W25MHZ |
| A1668 | PNP | 28B | 电源 开关 | 200V2A25W20MHZ |
| A1785 | PNP | BCE | 驱动 | 400V1A1W/120V1A0.9W140MH |
| A1941 | PNP | BCE | 功放开关 | 140V10A100WCOP:5198 |
| A1943 | PNP | BCE | 功放 开关 | 230V15A150W /C5200 原 |
| A1988 | PNP | 30 | 功放 开关 | |
| B449 | PNP | 12 | 功放开关 | 50V3.5A22.5W 褚管 |
| B631K | PNP | 29 | 音频功放开关 | 120V1A8W130MHZ /D600K |
| B647 | PNP | 21 | 通用 | 120V1A0.9W140MHZ /D667 |
| B649 | PNP | 29 | 视放 | 180V1.5A1W /D669 |
| B669 | PNP | 28 | 达林顿 功放 | 70V4A40W |
| B673 | PNP | 28 | 达林顿 功放 | 100V7A40W |
| B675 | PNP | 28 | 达林顿 功放 | 60V7A40W |
| B688 | PNP | BCE | 音频功放开关 | 120V8A80W /D718 |
| B734 | PNP | 39B | 通用 | 60V1A1W /D774 |
| B744 | PNP | 21 | 通用 | 30V0.1A0.25W |
| B772 | PNP | 29 | 音频功放开关 | 40V3A10W |
| B774 | PNP | 21 | 通用 | 30V0.1A0.25W |

| | | | | |
|-------|-----|-----|--------|---------------------------------|
| B817 | PNP | 30 | 功放开关 | 160V12A100W /D1047 |
| B834 | PNP | 28 | 功放开关 | 60V3A30W |
| B937A | PNP | | 功放开关 | 60V2A35 DRAL |
| B1020 | PNP | 28 | 功放开关 | 达林顿100V7A40W β =6000 |
| B1079 | PNP | 30 | 达林顿功放 | 100V20A100W β =5000/D1559 |
| B1185 | PNP | 28B | 功放开关 | 60V3A25W 70MHZ /D1762 |
| B1238 | PNP | ECB | 功放开关 | 80V0.7A1W 100MHZ |
| B1240 | PNP | 39B | 功放开关 | 40V2A1W100HZ |
| B1243 | PNP | 39B | 功放开关 | 40V3A1W70HZ |
| B1316 | PNP | 54B | 驱动功放 | 达林顿100V2A10W β =15000 |
| B1317 | PNP | BCE | 音频功放 | 180V15A150W COP:D1975 |
| B1335 | PNP | 28 | 音频功放低噪 | 80V4A30W 12MHZ |
| B1375 | PNP | BCE | 音频功放 | 60V3A2W9MHZ |
| B1400 | PNP | 28B | 达林顿功放 | 120V6A25W β =1000-20000 |
| B1429 | PNP | BCE | 功放开关 | 180V15A150W |
| B1494 | PNP | BCE | 达林顿功放 | 120V25A120W β =2000-20000 |
| C106 | NPN | EBC | 音频功放开关 | 60V1.5A15W |
| C380 | NPN | 21 | 高频放大 | 35V0.03A250MHZ |
| C458 | NPN | 21 | 通用 | 30V0.1A230MHz |
| C536 | NPN | 21 | 通用 | 40V0.1A180MHZ |
| C752 | NPN | 21 | 通用 | 30V0.1A300MHZ |
| C815 | NPN | 21 | 通用 | 60V0.2A0.25W |
| C828 | NPN | 21 | 通用 | 45V0.05A0.25W |
| C900 | NPN | 21 | 低噪放大 | 30V0.03A100MHZ |
| C943 | NPN | 4A | 通用 | 60V0.2A200MHZ |
| C945 | NPN | 21 | 通用 | 50V0.1A0.5W250MHZ |
| C1008 | NPN | 6 | 通用 | 80V0.7A0.8W50MHZ |
| C1162 | NPN | 29 | 音频功放开关 | 35V1.5A10W |
| C1213 | NPN | 39B | 监视器专用 | 35V0.5A0.4W |
| C1222 | NPN | 21 | 低噪放大 | 60V0.1A100MHZ |

| | | | | |
|---------|-----|-----|--------|-------------------------|
| C1494 ? | NPN | 40A | 发射 | 36V6A PQ=40W/175MHZ |
| C1507 | NPN | 28 | 视放 | 300V0.2A15W |
| C1674 | NPN | 21 | HF/ZF | 30V0.02A600MHZ |
| C1815 | NPN | 21 | 通用 | 60V0.15A0.4W8MHZ |
| C1855 | NPN | 21f | HF/ZF | 20V0.02A550MHZ |
| C1875 | NPN | 12 | 彩行 | 1500V3.5A50W |
| C1906 | NPN | 21 | 高频放大 | 30V0.05A1000MHZ |
| C1942 | NPN | 12 | 彩行 | 1500V3A50W |
| C1959 | NPN | 21 | 通用 | 30V0.4A0.5W300MHZ |
| C1970 | NPN | 28 | 手机发射 | 40V0.6A PQ=1.3W/175MHZ |
| C1971 | NPN | 28A | 手机发射 | 35V2.0A PQ=7.0W/175MHZ |
| C1972 | NPN | 28A | 手机发射 | 35V3.5A PQ=15W/175MHZ |
| C2012 | NPN | 21 | HF | 30V0.03A200MHZ |
| C2027 | NPN | 12 | 行管 | 1500V5A50W |
| C2036 | | | | |
| C2068 | NPN | 28E | 视频放大 | 300V0.05A1.5W80MHZ |
| C2073 | NPN | 28 | 功率放大 | 150V1.5A25W4MHZ /A940 |
| C2078 | NPN | 28 | 音频功放开关 | 80V3A10W150MHZ |
| C2120 | NPN | 21 | 通用 | 30V0.8A0.6W |
| C2228 | NPN | 21 | 视频放大 | 160V0.05A0.75W |
| C2230 | NPN | 21 | 视频放大 | 200V0.1A0.8W |
| C2233 | NPN | 28 | 音频功放开关 | 200V4A40W |
| C2236 | NPN | 21 | 通用 | 30V1.5A0.9W /A966 |
| C2238 | NPN | 28 | 音频功放开关 | 160V1.5A25W100MHZ /A968 |
| C2320 | NPN | 21 | 通用 | 50V0.2A0.3W200MHZ |
| C2335 | NPN | 28 | 视频 功放 | 500V7A40W |
| C2373 | NPN | 28 | 功放 | 200V7.5A40W |
| C2383 | NPN | 21 | 视频 开关 | 160V1A0.9W /A1015 |
| C2443 | NPN | 大铁 | 功放开关 | 600V50A400W |
| C2481 | NPN | 29 | 音频功放开关 | 150V1.5A20W |

| | | | | |
|-------|-----|-----|--------|-------------------------------|
| C2482 | NPN | 21 | 视频放大 | 300V0.1A0.9W |
| C2500 | NPN | 21 | 通用 | 30V2A0.9W150MHZ |
| C2594 | NPN | 29 | 音频功放开关 | 40V5A10W |
| C2611 | NPN | 29 | 视频放大 | 300V0.1A1.25W |
| C2625 | NPN | 30 | 音频功放开关 | 450V10A80W |
| C2682 | NPN | 29 | NF/Vid | 180V0.1A8W |
| C2688 | NPN | 29 | 视放管 | 300V0.2A10W80MHZ |
| C2690 | NPN | 29 | 音频功放开关 | 120V1.2A20W150MHZ/A1220P |
| C2751 | NPN | BCE | 电源开关 | 500V15A120W $\beta=40$ |
| C2837 | NPN | 30 | 音频功放开关 | 150V10A100W |
| C2898 | NPN | 28 | 音频功放开关 | 500V8A50W |
| C2922 | NPN | 43 | 音频功放开关 | 180V17A200W50MHZ /A1216 |
| C3026 | NPN | 12 | 开关管 | 1700V5A50W $\beta=20$ |
| C3030 | NPN | BCE | 开关管 | 达林顿900V7A80W $\beta=15$ |
| C3039 | NPN | 28 | 电源开关 | 500V7A50W $\beta=40$ |
| C3058 | NPN | 12 | 开关管 | 600V30A200W $\beta=15$ |
| C3148 | NPN | 28 | 电源开关 | 900V3A40W $\beta=15$ |
| C3150 | NPN | 28 | 电源开关 | 900V3A50W $\beta=15$ |
| C3153 | NPN | 30 | 电源开关 | 900V6A100W $\beta=15$ |
| C3182 | NPN | 30 | 功放开关 | 140V10A100W $\beta=95/A1265$ |
| C3198 | NPN | 21 | 高频放大 | 60V0.15A0.4W130MHZ |
| C3262 | NPN | BCE | 达林顿功放 | 800V10A100W |
| C3264 | NPN | BCE | PA功放开关 | 230V17A200W $\beta=170/A1295$ |
| C3280 | NPN | 30 | 音频功放开关 | 160V12A120W $\beta=100$ |
| C3281 | NPN | 30 | 音频功放开关 | 200V15A150W30MHZ $\beta=100$ |
| C3300 | NPN | 30 | 音频功放开关 | 100V15A100W $\beta=600$ |
| C3310 | NPN | 28C | 电源开关 | 500V5A40W $\beta= 20$ |
| C3320 | NPN | 28C | 电源开关 | 500V15A80W $\beta= 15$ |
| C3355 | NPN | 21F | 高频放大 | 20V0.1A6500MHZ |
| | | | | |

| | | | | |
|-------|-----|-----|--------|-------------------------|
| C3358 | NPN | 40B | 高频放大 | 20V0.1A7000MHZ |
| C3457 | NPN | BCE | 电源开关 | 1100V3A50W $\beta=12$ |
| C3460 | NPN | BCE | 电源开关 | 1100V6A100W $\beta=12$ |
| C3466 | NPN | BCE | 电源开关 | 1200V8A120W $\beta=10$ |
| C3505 | NPN | 28B | 电源开关 | 900V6A80W $\beta=20$ |
| C3527 | NPN | BCE | 电源开关 | 500V15A100W $\beta=13$ |
| C3528 | NPN | BCE | 电源开关 | 500V20A150W $\beta=13$ |
| C3595 | NPN | 29 | 射频 | 30V0.5A1.2W $\beta=90$ |
| C3679 | NPN | BCE | 电源开关 | 900V5A100W6MHZ |
| C3680 | NPN | BCE | 电源开关 | 900V7A120W6MHZ |
| C3688 | NPN | BCE | 彩行 | 1500V10A150W |
| C3720 | NPN | BCE | 彩行 | 1200V10A200W |
| C3783 | NPN | BCE | 高压高速开关 | 900V5A100W 黄河21" |
| C3795 | NPN | BCE | 高压高速开关 | 900V5A2W8MHz |
| C3807 | NPN | BCE | 低噪放大 | 30V2A1.2W260MHZ |
| C3858 | NPN | BCE | 功放开关 | 200V17A200W20MHZ /A1494 |
| C3866 | NPN | BCE | 高压高速开关 | 900V3A40W |
| C3873 | NPN | BCE | 高压高速开关 | 500V12A75W30MHZ |
| C3886 | NPN | BCE | 开关,行管 | 1400V8A50W8MHZ |
| C3893 | NPN | 28B | 行管 | 1400V8A50W8MHZ |
| C3907 | NPN | 28B | 功放开关 | 180V12A130W30MHZ |
| C3953 | NPN | 29 | 视放 | 120V0.2A1.3W 4000MHZ |
| C3987 | NPN | 28 | 达林顿 | 50V3A20W $\beta=1000$ |
| C3995 | NPN | BCE | 行管 | 1500V12A180W 34寸 |
| C3997 | NPN | BCE | 行管 | 1500V15A250W |
| C3998 | NPN | BCE | 行管 | 1500V25A250W |
| C4024 | NPN | BCE | 功放开关 | 100V10A35W 24MHZ |
| C4038 | NPN | BCE | 门电路 | 50V0.1A0.3W180MHZ |
| C4059 | NPN | BCE | 高速开关 | 600V15A130W 0.5/2.2US |
| C4106 | NPN | BCE | 电源开关 | 500V7A50W20MHZ? |

| | | | | |
|--------|-----|-----|-----------|----------------------|
| C4111 | NPN | BCE | 开关 行管 | 1500V10A150W |
| C4119 | NPN | BCE | 微波炉 开关 | 1500V15A250W |
| C4231 | NPN | 50C | 音频功放 | 800V2A30W |
| C4237 | NPN | BCE | 高压高速开关 | 1000V8A120W30MHZ |
| C4242 | NPN | BCE | 高压高速开关 | 450V7A40W |
| C4288 | NPN | BCE | 行管 | 1400V12A200W8MHZ |
| C4297 | NPN | BCE | 电源开关 | 500V12A75W10MHZ |
| C4429 | NPN | BCE | 电源开关 | 1100V8A60W |
| C4517 | NPN | BCE | 音频功放 | 550V3A30W6MHZ |
| C4532 | NPN | BCE | | |
| C4582 | NPN | 28b | 电源开关 | 600V15A75W20MHZ |
| ON4673 | NPN | BCE | | |
| ON4873 | NPN | BCE | | |
| C4706 | NPN | BCE | 电源开关 | 900V14A130W6MHz |
| C4742 | NPN | 46 | 彩行 | 1500V6A50W(带阻尼) |
| C4745 | NPN | 46 | 彩行 | 1500V6A50W |
| C4747 | NPN | 46 | 彩行 | 1500V10A50W |
| C4769 | NPN | BCE | 微机行管 | 1500V7A60W(带阻尼) |
| C4913 | NPN | BCE | 大屏视放管 | 2000V0.2A35W |
| C4924 | NPN | BCE | 音频功放 | 800V10A70W |
| C4927 | NPN | BCE | 行管 | 1500V8A50W |
| C4927 | NPN | BCE | SONY29"行管 | 1500V8A50W 原装 |
| C4941 | NPN | BCE | 行管 | 1500V6A65W 500/380NS |
| C4953 | NPN | BCE | | 500V2A25W |
| C5020 | NPN | BCE | 彩行 | 1000V7A100W |
| C5068 | NPN | BCE | 彩行 | 1500V10A50W |
| C5086 | NPN | BCE | 彩行 | 1500V10A50W |
| C5088 | NPN | BCE | 彩行 | 1500V10A50W |
| C5129 | NPN | BCE | 彩显行管 | 1500V8A50W(带阻) |
| C5132 | NPN | BCE | 彩行 | 1500V16A50W |

| | | | | |
|-------|-----|-----|--------|-----------------------|
| C5144 | NPN | BCE | 大屏彩行 | 1700V20A200W |
| C5148 | NPN | BCE | | |
| C5149 | NPN | BCE | 高速高频行管 | 1500V8A50W(带阻) |
| C5198 | NPN | BCE | 功放开关 | 140V10A100W |
| C5200 | NPN | BCE | 功放开关 | 230V15A150W /A1943 原 |
| C5207 | NPN | BCE | 彩行 | 1500V10A50W 原 |
| C5243 | NPN | BCE | 彩行 | 1700V15A200W 原 |
| C5244 | NPN | BCE | 彩行 | 1700V15A200W |
| C5249 | NPN | BCE | | |
| C5250 | NPN | BCE | 开关 | 1000V7A100W 原 |
| C5251 | NPN | BCE | 彩行 | 1500V12A50W 原 |
| C5252 | NPN | BCE | 彩行 | 1500V15A100W 原 |
| C5294 | NPN | BCE | | |
| C5296 | NPN | BCE | 开关管 | 25"--34"大屏彩显电源管 |
| C5297 | NPN | BCE | 开关管 | 25"--34"大屏彩显电源管 |
| C5331 | NPN | BCE | 大屏彩显行管 | 1500V15A180W |
| C5423 | NPN | BCE | | |
| D40C | NPN | ECB | 对讲机用 | 40V0.5A40W75MHZ(达林顿) |
| D325 | NPN | BCE | 功放开关 | 50V3A25W |
| D385 | NPN | 11 | 达林顿功放 | 100V7A30W |
| D400 | NPN | 21 | 通用 | 25V1A0.75W |
| D401 | NPN | 28 | 音频功放开关 | 200V2A20W |
| D415 | NPN | 29 | 音频功放开关 | 120V0.8A5W |
| D438 | NPN | 21 | 通用 | 500V1A0.75W100MHz |
| D547 | NPN | 大铁 | 功放开关 | 600V50A400W |
| D560 | NPN | BCE | 达林顿功放 | 150V5A30W |
| D600K | NPN | 29 | 音频功放开关 | 120V1A8W130MHZ/B631K |
| D637 | NPN | 39E | 通用 | 60V0.1A150MHZ **** |
| D667 | NPN | 21 | 视频放大 | 120V1A0.9W140MHZ/B647 |
| D669 | NPN | 29 | 视频放大 | 180V1.5A1W140MHZ/D669 |

| | | | | |
|--------|-----|-----|--------|-------------------------------|
| D718 | NPN | 30 | 音频功放开关 | 120V8A80W /B668 |
| D774 | NPN | 39B | 通用 | 100V1A1W /B734 |
| D789 | NPN | 21 | 音频输出 | 100V1A0.9W |
| D820 | NPN | 12 | 彩行 | 1500V5A50W |
| D870 | NPN | 12 | 彩行 | 1500V5A50W RRRR |
| D880 | NPN | 28 | 音频功放开关 | 60V3A10W |
| D882 | NPN | 29 | 音频功放开关 | 40V3A30W |
| D884 | NPN | 28 | 音频功放开关 | 330V7A40W |
| D898 | NPN | 12 | 彩行 | 1500V3A50W |
| D951 | NPN | 12 | 彩行 | 1500V3A65W |
| D965 | NPN | 21 | 音频 | 40V5A0.75W |
| D966 | NPN | 21 | 音频 | 40V5A1W |
| D985 | NPN | 29 | 功放 | 150V1.5A10W |
| D986 | NPN | 29 | 功放 | 150V1.5A10W |
| D1025 | NPN | 28 | 达林顿功放 | 200V8A50W |
| D1037 | NPN | BCE | 音频功放开关 | 150V30A180W |
| D1047 | NPN | 30 | 音频功放开关 | 160V12A100W /B817 |
| D1071 | NPN | 28 | 功放 | 300V6A40W DRA-L |
| D1163A | NPN | 28 | 行偏转用 | 350V7A40W60MHz |
| D1175 | NPN | 12 | 行偏转用 | 1500V5A100W $\beta=15$ 原 |
| D1273 | NPN | 28 | 音频功放 | 80V3A40W50MHZ $\beta=1500$ |
| D1302 | NPN | 21 | 音频 | 25V0.5A0.5W200MHZ |
| D1397 | NPN | BCE | 开关 | 1500V3.5A50W3MHz |
| D1398 | NPN | BCE | 开关 | 1500V5A50W3MHz |
| D1403 | NPN | 28B | 彩行 | 1500V6A120W |
| D1403 | NPN | 28B | 彩行 | 1500V6A120W 原 |
| D1415 | NPN | 28B | 功放电源开关 | 100V7A40W $\beta=6000$ 达林顿 |
| D1416 | NPN | 28B | 功放电源开关 | 80V7A40W $\beta=6000$ (达林顿) |
| D1426 | NPN | 28B | 彩行 | 1500V3.5A80W $\beta=12$ RRRRR |
| D1427 | NPN | 28B | 彩行 | 1500V5A80W $\beta=12$ RRRRR |

| | | | | |
|-------|-----|-----|--------|---------------------------------|
| D1428 | NPN | 28B | 彩行 | 1500V6A80W $\beta=12$ RRRR |
| D1431 | NPN | 28B | 彩行 | 1500V5A80W $\beta=20$ |
| D1433 | NPN | 28B | 彩行 | 1500V7A80W $\beta=20$ |
| D1439 | NPN | BCE | 彩行 | 1500V3A80W $\beta=8$ |
| D1541 | NPN | 28B | 彩行 | 1500V3A80W $\beta=20$ |
| D1545 | NPN | 28B | 彩行 | 1500V5A50W $\beta=20$ |
| D1547 | NPN | BCE | 彩行 | 1500V7A80W $\beta=20$ |
| D1554 | NPN | BCE | 彩行 | 1500V3.5A80W $\beta=12$ |
| D1555 | NPN | BCE | 彩行 | 1500V5A80W $\beta=12$ |
| D1556 | NPN | BCE | 彩行 | 1500V6A80W $\beta=12$ |
| D1559 | NPN | BCE | 达林顿功放 | 100V20A100W $\beta=5000$ /B1079 |
| D1590 | NPN | 28 | 达林顿功放 | 150V8A25W $\beta=15000$ |
| D1632 | NPN | 28B | 彩行 | 1500V4A70W |
| D1640 | NPN | 29 | 达林顿功放 | 120V2A1.2W $\beta=4000-40000$ |
| D1651 | NPN | SP | 彩行 | 1500V5A60W3MHZ |
| D1710 | NPN | BCE | 彩行 | 1500V5A50W |
| D1718 | NPN | 28C | 音频功放 | 180V15A3.5W20MHZ |
| D1762 | NPN | BCE | 音频功放开关 | 60V3A25W90MHZ /B1185 |
| D1843 | NPN | BCE | 低噪 放大 | 50V1A1W |
| D1849 | NPN | 50A | 彩行 | 1500V7A120W |
| D1850 | NPN | 50A | 彩行 | 1500V7A120W |
| D1859 | NPN | 50A | 音频 | 80V0.7A1W120MHZ |
| D1863 | NPN | 50A | 音频 | 120V1A1W100MHZ |
| D1877 | NPN | 30 | 彩行 | 1500V4A50W(带阻尼) |
| D1879 | NPN | 30 | 彩行 | 1500V6A60W(带阻尼) |
| D1887 | NPN | 30 | 彩行 | 1500V10A70W |
| D1930 | NPN | 21 | 达林顿 | 达林顿100V2A1.2W $\beta=1000$ |
| D1975 | NPN | 53A | 音频功放 | 180V15A150W COP:B1317 |
| D1978 | NPN | 21 | 达林顿 | 120V1.5A0.9W $\beta=30000$ |
| | | | | |

| | | | | |
|--------|-----|-----|--------|---------------------------------|
| D1980 | NPN | 61B | 达林顿 | 100V2A10W β =1000-10000 |
| D1981 | NPN | ECB | 达林顿 | 100V2A1W |
| D1993 | NPN | 45B | 音频低噪 | 55V0.1A0.4W |
| D1994A | NPN | ECB | 音频驱动 | 60V1A1W |
| D1997 | NPN | 45B | 激励管 | 40V3A1.5W100MHZ |
| D2008 | NPN | ECB | 音频功放 | 80V1A1.2W |
| D2012 | NPN | BCE | 音频功放 | 60V3A2W3MHZ |
| D2136 | NPN | ECB | 功放 | 80V1A1.2W |
| D2155 | NPN | 53A | 音频功放 | 180V15A150W |
| D2256 | NPN | 46 | 达林顿功放 | 120V25A125W β =2000-20000 |
| D2334 | NPN | 28B | 彩行 | 1500V5A80W |
| D2335 | NPN | BCE | 彩行 | 1500V7A100W |
| D2349 | NPN | BCE | 大屏彩显行管 | |
| D2374 | NPN | BCE | | |
| D2375 | NPN | BCE | | |
| D2388 | NPN | EBC | 达林顿 | 90V3A1.2W |
| D2445 | NPN | BCE | 彩行 | 1500V12.5A120W |
| D2498 | NPN | BCE | 彩行 | 1500V6A50W |
| D2588 | NPN | BCE | 点火器用 | |
| DK55 | NPN | BEC | 开关 | 400V4A60W |
| BC307 | PNP | 21a | 通用 | 50V0.2A0.3W |
| BC327 | PNP | CBE | 低噪 音频 | 50V0.8A0.625W COM BC337 |
| BC337 | NPN | 21a | 音频激励低噪 | 50V0.8A0.625W COM BC327 |
| BC338 | NPN | 21a | 通用 激励 | 50V0.8A0.6 |
| BC546 | NPN | 21a | 通用 | 80V0.2A0.5W |
| BC547 | NPN | CBE | 通用 | 50V0.2A0.5W300MHZ |
| BD135 | NPN | 29 | 音频 功放 | 45V1.5A12.5W |
| BD136 | PNP | 29 | 音频 功放 | 45V1.5A12.5W |
| BD137 | NPN | 29 | 音频 功放 | 60V1.5A12.5W |
| BD138 | PNP | 29 | 音频 功放 | 60V1.5A12.5W |

| | | | | |
|----------|-----|----|-------|------------------------|
| BD139 | PNP | 29 | 音频 功放 | 80V1.5A12.5W |
| BD237 | NPN | 29 | 音频 功放 | 100V2A25W |
| BD238 | PNP | 29 | 音频 功放 | 100V2A25W |
| BD243 | NPN | 28 | 音频 功放 | 45V6A65W |
| BD244 | PNP | 28 | 音频 功放 | 45V6A65W |
| BD681 | NPN | 29 | 达林顿功放 | 100V4A40W |
| BD682 | NPN | 29 | 达林顿功放 | 100V4A40W |
| BF458 | NPN | 29 | 视放 | 250V0.1A10W |
| BU208A | NPN | 12 | 彩行 | 1500V5A12.5W |
| BU208D | NPN | 12 | 彩行 | 1500V5A12.5W (带阻尼) |
| BU323 | NPN | 28 | 达林顿功放 | 450V10A125W |
| BU406 | NPN | 28 | 行管 | 400V7A60W |
| BU508A | NPN | 28 | 行管 | 1500V7.5A75W |
| BU508A | NPN | 28 | 行管 | 1500V7.5A75W 原 |
| BU508D | NPN | 28 | 行管 | 1500V7.5A75W (带阻尼) |
| BU806 | NPN | 28 | 功放 | 400V8A60W DAR-L |
| BU932R | NPN | 12 | 功放 | 500V15A150W DAR-L |
| BU941 | NPN | 12 | | |
| BU1508DX | NPN | 28 | 开关 功放 | |
| BU2506DX | NPN | 30 | 开关 功放 | 1500V7A50W /600NS |
| BU2508AF | NPN | 30 | 开关 功放 | 700V8A125W /600NS |
| BU2508AX | NPN | 30 | 开关 功放 | 700V8A125W /600NS |
| BU2508DF | NPN | 30 | 开关 功放 | 700V8A125W/600NS(带阻尼) |
| BU2508DX | NPN | 30 | 开关 功放 | 1500V8A50W/600NS(带阻尼) |
| BU2520AF | NPN | 30 | 开关 功放 | 800V10A150W 1/500NS |
| BU2520AX | NPN | 30 | 开关 功放 | 1500V10A150W 1/500NS |
| BU2520DF | NPN | 30 | 开关 功放 | 800V10A150W1/500NS(带阻) |
| BU2520DX | NPN | 30 | 开关 功放 | 1500V10A50W/600NS (带阻) |
| BU2522AF | NPN | 30 | 开关 功放 | 1500V11A150W /350NS |
| BU2522AX | NPN | 30 | 开关 功放 | 1500V11A150W /350NS |

| | | | | |
|----------|-----|-----|---------|------------------------|
| BU2525AF | NPN | 30 | 开关 功放 | 1500V12A150W /350NS |
| BU2525AX | NPN | 30 | 开关 功放 | 1500V12A150W /350NS |
| BU2527AF | NPN | 30 | 开关 功放 | 1500V15A150W |
| BU2532AW | NPN | 30 | 开关 功放 | 1500V15A150W(大屏) |
| BUH515 | NPN | BCE | 行管 | 1500V10A80W |
| BUH515D | NPN | BCE | 行管 | 1500V10A80W(带阻尼) |
| BUS13A | NPN | 12 | 开关 功放 | 1000V15A175W |
| BUS14A | NPN | 12 | 开关 功放 | 1000V30A250W |
| BUT11A | NPN | 28 | 开关 功放 | 1000V5A100W |
| BUT12A | NPN | 28 | 开关 功放 | 450V10A125W |
| BUV26 | NPN | 28 | 音频功放开关 | 90V14A65W /250ns |
| BUV28A | NPN | 28 | 音频功放开关 | 225V10A65W /250ns |
| BUV48A | NPN | 30 | 音频功放开关 | 450V15A150W |
| BUW13A | NPN | 30 | 功放开关 | 1000V15A150W |
| BUX48 | NPN | 12 | 功放开关 | 850V15A125W |
| BUX84 | NPN | 30 | 功放开关 | 800V2A40W |
| BUX98A | NPN | 12 | 功放开关 | 400V30A210W5MHZ |
| DTA114 | PNP | | 10K-10K | 160V0.6A0.625W(带阻) |
| DTC143 | NPN | | 录像机用 | 4.7K-4.7K |
| HPA100 | NPN | BCE | 大屏彩显行管 | 21# |
| HPA150 | NPN | BCE | 大屏彩显行管 | 21# |
| HSE830 | PNP | BCE | 音频功放 | 80V115W1MHZ |
| HSE838 | NPN | BCE | 音频功放 | 80V115W1MHZ COP/MJ4502 |
| MN650 | NPN | BCE | 行管 | 1500V6A80W |
| MJ802 | NPN | 12 | 音频功放开关 | 90V30A200W |
| MJ2955 | PNP | 12 | 音频功放开关 | 60V15A115W |
| MJ3055 | NPN | 12 | 音频功放开关 | 60V15A115W |
| MJ4502 | PNP | 12 | 音频功放开关 | 90V30A200W COP/MJ802 |
| MJ10012 | NPN | 12 | 达林顿 | 400V10A175W |
| MJ10015 | NPN | 12 | 电源开关 | 400V50A200W |

| | | | | |
|----------|-----|-----|--------|-------------------------|
| MJ10016 | NPN | 12 | 电源开关 | 500V50A200W |
| MJ10025 | | 12 | 电源开关 | 850V20A250W |
| MJ11032 | NPN | 12 | 电源开关 | 120V50A300W DAR-L |
| MJ11033 | PNP | 12 | 电源开关 | 120V50A300W DAR-L |
| MJ13333 | NPN | 12 | 电源开关 | 400V20A175W |
| MJ15024 | NPN | 12 | 音频功放开关 | 400V16A250W4MHZ(原25.00) |
| MJ15025 | PNP | 12 | 音频功放开关 | 400V16A250W4MHZ(原25.00) |
| MJE271 | PNP | 29 | 达林顿 | |
| MJE340 | NPN | 29 | 视放 | 300V0.5A20W |
| MJE350 | PNP | 29 | 视放 | 300V0.5A20W |
| MJE2955T | PNP | BCE | 音频功放开关 | 60V1075W2MHZ |
| MJE3055T | NPN | BCE | 音频功放开关 | 70V1075W2MHZ |
| MJE5822 | PNP | BCE | 音频功放开关 | 500V8A |
| MJE9730 | NPN | BCE | | |
| MJE13003 | NPN | 29 | 功放开关 | 400V1.5A14W |
| MJE13005 | NPN | 28 | 功放开关 | 400V4A60W |
| MJE13007 | NPN | 28 | 功放开关 | 1500V2.5A60W |
| SE800 | | | | |
| TIP31C | NPN | BCE | 功放开关 | 100V3A40W3MHZ |
| TIP32C | PNP | BCE | 功放开关 | 100V3A40W3MHZ |
| TIP35C | NPN | 30 | 音频功放开关 | 100V25A125W3MHZ |
| TIP36C | PNP | 30 | 音频功放开关 | 100V25A125W3MHZ |
| TIP41C | NPN | 30 | 音频功放开关 | 100V6A65W3MHZ |
| TIP42C | PNP | 30 | 音频功放开关 | 100V6A65W3MHZ |
| TIP102 | NPN | 28 | 音频功放开关 | 100V8A2W |
| TIP105 | | 28 | 音频功放开关 | |
| TIP122 | NPN | 28 | 音频功放开关 | 100V8A65W DARL |
| TIP127 | PNP | 28 | 音频功放开关 | 100V8A65W DARL |
| TIP137 | PNP | 28 | 音频功放开关 | 100V8A70W DARL |
| TIP142 | NPN | 30 | 音频功放开关 | 100V10A125W DAR-L |

| | | | | |
|---------|-----|-----|--------|---------------------|
| TIP142大 | NPN | 30 | 音频功放开关 | 100V10A125W DAR-L |
| TIP147 | PNP | 30 | 音频功放开关 | 100V10A125W DAR-L 0 |
| TIP147大 | PNP | 30 | 音频功放开关 | 100V10A125W DAR-L 0 |
| TIP152 | | | 电梯用 | |
| TL431 | | 21 | 电压基准源 | |
| UGN3120 | | SGO | 霍尔开关 | |
| UGN3144 | | SGO | 霍尔开关 | |
| 60MIAL1 | | | 电磁/微波炉 | 1000V60A300W |
| T30G40 | NPN | BCE | 大功率开关管 | 400V30A300W |
| 5609 | | | | COML:5610 |
| 5610 | | | | COML:5609 |
| 9626 | | | | NPN21 通用 |